

Connecting a Digi 002 to a Central Station and HP4 for speaker switching plus 2.1

002 front



Central Station front



002 back



Central Station back



What you'll need:

- (2) TS -TS cables
- (2) XLR(F) - XLR(M) cables
- (6) TRS - XLR(M) cables
- (4) TRS - TRS cables