



HONEYTONE™

N-10™



© EC 1998 Printed in China

OWNER'S MANUAL



*Danelectro always made insanely great gear.
We pioneered tube amps in the 40's. Our guitars
were king of the rock scene in the 50's and 60's.*

Top players still love them.

Collectors snap them up.

Now we're back with great vintage gear.

Own the sounds of yesteryear!

HEARING IS BELIEVING.

EEC Agent:

John Hornby Skewes & Co., Ltd.

Salem House, Parkinson Approach, Garforth, Leeds LS25 2HR UK

INSTRUCTIONS


HONEY TONE™

1. *Insert instrument cable into IN jack.*
2. *Use 9V battery (Danelectro® Vintage Battery) or Danelectro DA-1 AC Adaptor. Power adaptor must be center negative, 9 Volts, 300mA maximum.*
3. *Turn on the amplifier using the OFF/VOLUME control. Set VOLUME to desired setting.*
4. *Adjust TONE control for desired bass/treble setting.*
5. *Adjust O. DRIVE control for desired distortion.*
6. *To use HEADPHONE, connect plug from Walkman® type headphones to the HEADPHONE jack.*
7. *When sound quality or volume level is degraded, replace the battery.*

Caution: Loud volume levels through speaker or headphone can cause hearing damage. Please use appropriate volume levels.


CONTROL SETTINGS

CLEAN & SPANKY




CONTROL SETTINGS

WARM JAZZ




CONTROL SETTINGS

BIG AMP OVERDRIVE




CONTROL SETTINGS

KILLER BLUES




CONTROL SETTINGS

DISTORTED RHYTHM




CONTROL SETTINGS

THICK SOLO




CONTROL SETTINGS

WOODSTOCK FUZZ




CONTROL SETTINGS

“SEND THE CATS UNDER THE BED”




CONTROL SETTINGS

TWANG




CONTROL SETTINGS

MONDO SUSTAIN




CONTROL SETTINGS

BRIT SOLO TUNE




CONTROL SETTINGS

SPARKLE CLEAN




CONTROL SETTINGS

EARLY 80'S (CLEAN) SOLO




CONTROL SETTINGS

LATE 60'S NECK SOLO



CONTROL SETTINGS

70'S BRIT



CONTROL SETTINGS

70'S SOLO

